



Image not found or type unknown




Image not found or type unknown




Image not found or type unknown




Image not found or type unknown




Image not found or type unknown





Image not found or type unknown



100Hz 6dB

MF1是35Hz-1000Hz，最上方為250Hz，所以箭頭所指的地方大約是100Hz，綠色分類點調到這邊



這是0dB

衰減6dB大概在這邊



Image not found or type unknown




Image not found or type unknown




Image not found or type unknown




Image not found or type unknown




Image not found or type unknown




Image not found or type unknown





Image not found or type unknown



Revision #2

Created 23 June 2023 09:47:14 by bill

Updated 23 June 2023 09:52:12 by bill